


RESTRAINT SYSTEMS (CONT)

1352	97-98 R	79.41	m	0.5	F7LZ 14B004 AA
1353	97-98 L	83.66	m	0.5	F7LZ 14B005 AA
345	rear	93-94	m	0.5	F3LY 14B007 A
992		95-98	m	0.5	F5LY 14B007 A
346	Diagnostic unit	93-96	m	0.4	F2DZ 14B056 A
1354		97-98	m	0.4	F5TZ 14B056 B
347	bracket	93-96			F3LY 14B058 A
1355		97-98			F7LZ 14B058 AA
348	Res power module	93	m	0.5	FOVY 14B165 B

PARTS: Order by color.

† LABOR: Time is for visually checking flash codes, wiring, connectors, sensors and ensuring proper operation.

‡ LABOR: Time is for visually inspecting system, removal of air bag, installation of air bag simulator, install star tester, retrieve/clear trouble codes and reassemble.



FRONT SEAT BELTS


349	1 Retractor Assy	93 R	56.30 #	0.8	F3LY 63611B08 C
860		93 L	56.30 #	0.8	F3LY 63611B09 C
861		94-95 R	56.30 #	0.8	F4LY 63611B08 B
1356		94-95 L	56.30 #	0.8	F4LY 63611B09 B
1357		96 R	65.69 #	0.8	F6LY 63611B08 B
1358		96 L	65.69 #	0.8	F6LY 63611B09 B
1359		97-98 R	65.69 #	0.8	F7LZ 63611B08 AAD
1602		97-98 L	65.69 #	0.8	F7LZ 63611B09 AAD
784	2 Buckle	93-96 R	15.97 #	0.4	F3LY 6361202 C
994		93-96 L	15.97 #	0.4	F3LY 6361203 C
1603		97-98 R	18.63 #	0.4	F7LZ 6361202 AAA
1604		97-98 L	18.63 #	0.4	F7LZ 6361203 AAA
1605	3 Cover	93	9.32 #		F3LY 6360262 C
1606		94-97	9.32 #		F4LY 5460262 A
1607		98			F7LZ 5460262 AAA

REAR SEAT BELTS

353	4 Retractor Assy	93-96 R	49.24 #	1.0	F3LY 63611B68 C
354		93-96 L	49.24 #	1.0	F3LY 63611B69 C
1608		97-98 R	57.44 #	1.0	F7LZ 63611B68 AAE
1609		97-98 L	57.44 #	1.0	F7LZ 63611B69 AAE
355	5 Buckle	93-96 R	21.78 #	0.5	F3LY 6360044 C
356		93-96 L	21.78 #	0.5	F3LY 6360045 C
1607		97-98 R	25.41 #	0.5	F7LZ 6360044 AAA
1608		97-98 L	25.41 #	0.5	F7LZ 6360045 AAA

PARTS: Order by color.

SEATS & TRACKS



PARTS AND R&R OPERATIONS

FRONT SEAT COMPONENTS


457	1 Seat back adjust	93-98 R	282.54	0.7	F3LY 6362648 A
458	w/ auto glide	93-98 L	282.54	0.7	F3LY 6362649 A
459	w/ auto glide	93-96 R	282.54	0.7	F3LY 6362648 B
460	w/ auto glide	93-96 L	282.54	0.7	F3LY 6362649 B
1993		97-98 R	283.98	0.7	F7LY 6362648 AA
1994		97-98 L	282.54	0.7	F7LY 6362649 AA
1090	w/ power (RPO)	96-98 R	283.98	0.7	F5LZ 6362648 AC
1091		96-98 L	283.98	0.7	F5LZ 6362649 AC
1996	2 Side shield	93-95 R	102.61 #		F3LY 6362186 B
1997		93-95 L	22.94 #		F3LY 6362187 B
1998		96 R	102.61 #		F6LZ 6362186 AAE
1999		96 L	102.61 #		F6LZ 6362187 AAE
2000		97-98 R	102.61 #		F7LZ 6362186 AAD
2001		97-98 L	102.61 #		F7LZ 6362187 AAD
2002	3 Seat switch	93-96 R	166.15		F3LY 14A701 A
2003		93-96 L	159.77		F3LY 14A701 B
2004		97-98 R	50.07		F7LZ 14A701 AA
2005		97-98 L	139.85		F7LZ 14A701 BA
2006	4 Knob	97-98	2.98		F7LZ 14711 AC
2007	seat back adjust	97-98	2.98		F7LZ 14711 AB
2008	5 Control switch	93-96	49.97		F3LY 14C715 A
2009	lumbar & boosters	97-98	17.70		F4ZZ 14529 A

TRACKS & COMPONENTS

453	6 Track Assy	93-94 R	250.00 #	1.0	F3LY 6361710 DD
454	power seat	93-94 L	250.00 #	1.0	F3LY 6361711 DD
455	w/ auto glide	93-98 R	250.00 #	1.0	F3LY 6361710 DD
456	w/ auto glide	93-98 L	250.00 #	1.0	F3LY 6361711 DD
1094	w/ memory	96 R	250.00 #	1.0	F6LZ 6361704 AA
1095		96 L	250.00 #	1.0	F6LZ 6361705 AA
1476		97-98 R	250.00 #	1.0	F7LY 6361704 AA
1477		97-98 L	250.00 #	1.0	F7LY 6361705 AA
813	7 Shield	93-94 B	13.02 #		F3SZ 6362126 AAU
1609		95-97 B	38.24 #		F5AZ 5462126 AAB
1995		98 B	3.67 #		F6AZ 5462126 AAB

PARTS: Order by color.

ROOF



R&I OPERATIONS

358	R&I headliner	93-98	2.2		
-----	---------------	-------	-----	--	--

PARTS AND R&R OPERATIONS

359	1 Roof panel	(p4.0) 93-98	612.87	20.0	F3LY 6350202 B
360	w/ sunroof	(p4.5) 93-96	751.38	24.0	F3LY 6350202 A
1610	w/ sunroof	(p4.5) 97-98	620.77	24.0	F7LY 6350202 AA
263	2 Header panel	93-98	23.84	2.5	E9SZ 6303408 A
364	3 Roof bow	93-95	34.29 #	0.4	F1SZ 6350222 A
1097		96-98		0.4	NOT SERVICED


PARTS: Order by color.

361	4 Rear header	93-96	30.81 #	2.5	F3LY 6342220 A
1360		97-98	37.04 #	2.5	F7LZ 6342220 AA
362	Inner side rail	93-96 R	26.59 #	2.0	F3SZ 6351180 A
363		93-98 L	30.68 #	2.0	F3SZ 6351181 A

EXTERIOR TRIM

785	5 Rear molding	93-97 R	19.00 #	1.2	F7LZ 6351728 AA
786		93-97 L	19.00 #	1.2	F7LZ 6351729 AA
1611		98 R	19.00 #	1.2	F7LZ 6351728 AA
1612		98 L	19.00 #	1.2	F7LZ 6351729 AA
787	6 spacer	93-98 R	8.99		F3LY 63517016 BA
788		93-98 L	9.92		F3LY 63517017 BA


LABOR: After roof panel is removed.
‡ LABOR: Includes R&R quarter trim.



SUNROOF

368	1 Sunroof glass	93-96	2514.72	0.6	E9SZ 63502A82 A
1613	Ford	97-98	1050.26	0.6	F7SZ 63502A82 AAF
369	NAGS	93-96		0.6	DRO7510
1478		97-98		0.6	DRO9091
370	2 Housing	93-98		†	SEE FOOTNOTE
371	3 Rail Assy	93-96	260.25		E9SZ 6351070 A
1361		97-98	547.43		F7LZ 6351070 AA
372	4 Motor	93	458.56	1.0	F4LY 15790 A
995		94-96	510.77	1.0	F7LZ 15790 AA
1362		97-98	167.05	1.0	F4LY 15790 AA
373	5 Air deflector	93-96	140.11	0.3	E9SZ 63500A26 A
1363		97-98	142.36	0.3	F7LZ 63500A26 AA
374	6 Shield	93-98	103.80		E9SZ 6350988 A
375	7 Reinforcement	93-98	8.15		E7SZ 6351874 A
376	8 Trim panel	93-96	495.23 #	0.8	F1SZ 63519A02 AAQ
1364		97-98	552.23 #	0.8	F7LZ 63519A02 AAD
377	9 Retainer	93-96	74.12 #		F2SZ 6352124 B
1365	headliner	97-98	49.34 #		F7LZ 6352124 AAD

PARTS: Order by color and application.
† PARTS: Included with roof panel.



INTERIOR TRIM

639	1 Headliner	93-96	418.50 #	2.0	F3LY 6351916 AHA
1366	w/ sun roof	97	324.96 #	2.0	F7LZ 6351916 AAD
1614		98	324.96 #	2.0	F7LZ 6351916 AAE
640	w/ sun roof	93-96	418.50 #	2.0	F3LY 6351916 BHA
1367		97	324.96 #	2.0	F7LZ 6351916 AAJ
1615		98	324.96 #	2.0	F7LZ 6351916 AAK
641	2 Access cover	93-97	188.00 #		F0SZ 6352076 AAQ
1616		98	178.23 #		F8SZ 6352076 AAA
642	3 Retainer	93-98		†	SEE FOOTNOTE
276	Visor	93-94 R	264.75 #	0.4	F3LY 6304104 AHA
277	w/ moon roof	93-94 L	294.52 #	0.4	F3LY 6304105 AHA
998		95-96 R	130.45 #	0.4	F3LY 6304104 AHA
999		95-96 L	390.43 #	0.4	F3LY 6304105 AHA
1368		97 R	123.64 #	0.4	F7LZ 6304104 AHA
1369		97 L	395.94 #	0.4	F7LZ 6304105 CAE
1617		98 R	123.64 #	0.4	F7LZ 6304104 AAQ
1618		98 L	119.19 #	0.4	F7LZ 6304105 CAK
278	w/ moon roof	93-94 R	264.75 #	0.4	F3LY 6304104 BHA
279		93-94 L	294.52 #	0.4	F3LY 6304105 BHA

Please contact our Product Support Group if you require assistance locating, interpreting or using any information contained in this Estimating Guide. Toll Free Number: 1-800-426-6867.